

Compatible Android Device for Smart Pianist

Brand	Device Name	Model Number	OS
Google	Nexus 5X	-	8.1
Google	Nexus 6P	-	8.1
Google	Pixel	-	8.1
Google	Pixel XL	-	8.0
Google	Pixel 2	-	8.1
Google	Pixel 2 XL	-	8.1
Google	Pixel C	-	8.1
Samsung	Galaxy S8	SM-G9500	7.0
Samsung	Galaxy S8	SM-G950FD	8.0
Samsung	Galaxy S8 Plus	SM-G9550	7.0
Samsung	Galaxy S8 Plus	SM-G955FD	7.0
Samsung	Galaxy S7	SM-G930F	7.0
Samsung	Galaxy S7	SM-G930U	7.0
Samsung	Galaxy S7 Edge	SC-02H	7.0
Samsung	Galaxy S7 Edge	SM-G935FD	7.0
Samsung	Galaxy S7 Active	SM-G891A	7.0
Samsung	Galaxy S6	SM-G920F	6.0.1
Samsung	Galaxy S6 Edge	SCV31	7.0
Samsung	Galaxy S6 Edge Plus	SM-G928A	7.0
Samsung	Galaxy S6 Active	SM-G890A	7.0
Samsung	Galaxy Tab S3	SM-T820	7.0
Samsung	Galaxy Tab S2 8.0	SM-T713	7.0
Samsung	Galaxy Tab S2 8.0	SM-T710	6.0.1
Samsung	Galaxy Tab S2 9.7	SM-T813	7.0
Samsung	Galaxy Tab S2 9.7	SM-T810	7.0

ATTENTION

The Android devices listed above have been tested for compatibility with Smart Pianist, however Yamaha does not guarantee proper operation of such devices with Smart Pianist. Yamaha also takes no responsibility for any damage or inconvenience caused by The use of them.